

Mark Twain Toys – Wood Trimmed Pens/Pencils

Your new pen/pencil is made of quality materials with chrome, copper, or gold plated trim. Each wooden body is hand-turned on a lathe and polished with hard Carnauba wax that will last for years with minimal care.

Pens contain a “Parker” ballpoint pen refill available in most office supply stores. You may also use a gel refill of the same style. [1] To replace the refill on a twist pen: pull it apart at the arrow, to use the pen just twist. [2] To replace the refill on a click pen: unscrew the pen at the arrow, to use the pen click the button on top. [3] To refill a pencil: pull off the button on top, remove the eraser and add a few pieces of 0.5 mm polymer lead, to use the pencil click the button to advance the lead, hold the button and press the lead to retract it back in the pencil and then release the button.



Twist



Click